
# ALCATEL

E130 VOICE / E130 VOICE DLID / TRIO 6190 VOICE / 6190 VOICE DUO / TRIO



**GUÍA DE USUARIO** 

PLEASE READ THIS USER'S GUIDE BEFORE USING YOUR PHONE FAVOR DE LEER TODO EL MANUAL ANTES DE UTILIZAR SU TELÉFONO





# ENGLISH

# Before 1st use

# Connecting your phone:

- Connect plugs in corresponding sockets in the base station. Plug the telephone line into telephone socket and insert power plug in an electrical outlet.
- Insert batteries in handset.

Before you start to use your telephone, charge batteries continuously for 15 hours.

Only use plug adapter supplied with the unit and rechargeable batteries with your phone.

#### Phone Function Kevs

- 1 OK key 2 Back / Clear key
- Navigation key
  Talk key Handsfree (E190 Voice only) Hang-up / Exit key
- Recall (Flash) key Access to operator service\*
- Menu key Redial Key
- Start key
- 10 Hash key To lock or unlock / to toggle between the external and
- 11 Mute key 12 Call transfer/Intercom key



- B Displays when in menu mode to confirm your selection.
- C Indicates that more options are available. Use the UP / DOWN keys to scroll up/dow

#### What the icons meas?

- Indicates battery is fully charged. Indicates battery is fully discharged.
- Indicates that an external call is connected or held.
- Icon blinks when receiving an incoming call
- on Indicates you have a new voice mail message Indicates you have new missed calls\*, or the call log is being viewed.
- Displays when the phonebook is accessed. Displays when the alarm clock is activated.
- Displays when handsfree is activated (Sigma 260 Voice only).
- Displays when ringer volume is turned off. Indicates that the handset is registered and within range of the
- base station.
  Icon blinks when the handset is out of range or is searching for a
- Displays when in menu mode to confirm your selection
- Indicates that more options are available.
  Use the UP / DOWN keys to scroll up / down
- ⇒ Displays when in menu mode.
  Select BACK to return to the previous menu level.
- \* Subject to subscription and availability of the service from the fixed line

# Your Telephone Operations

#### Switching on / off

- Press and hold the of key.

- Notes: When the handset is OFF, it cannot be used for making calls including emergency calls. There will be no ringing during an incoming call
- To answer a call, you will need to switch it back on. It may take some time for the handset to re-establish a radio link with the base

#### To lock / unlock the keypad

- Press and hold the \*- kev.
- Note: Incoming calls can still be answered even if the keypad was locked

# Change the display language

- MENU/ ♠ or ▼ to select PERSONAL SET / □K / ♠ or ▼ to select LANGUAGE / DK / A or ▼ to your desired language / DK / confirmation been
- Note: Once the display language is set, the option menus on the handset will switch to display in the selected language immediately.

# Set time and date

Note: If you subscribe to the Caller Display service, the time and date will be set automatically when you receive a call, but you may still need to set the correct year.

- MENU/ A or T to select CLOCK & ALARM / NK / NK to select DATE / TIME to display the last stored date / enter the current (YY - MM - DD) / OK / enter the time (HH-MM) / OK.

#### Change your handset's name

MENU/ ♠ or ▼ to select PERSONAL SET / □K / ♠ or ▼ to select HANDSET NAME / OK to display the current handset name / = to delete the characters / enter the new name (maximum 10 characters) / DK/ confirmation beep.

# Make and answer calls

#### Make a call

- t either before or after dialing your number.
- From redial list: REDIAL / ♠ or ▼ / 🕻 - From call log list\*: ♣ /♠ or ▼ / 【
- Note: You need to subscribe to Caller Line Identification service to be able to see the caller's number or name in the call log.
- From phonebook: \(\mathbb{B}\) / \(\mathbb{A}\) or \(\nabla\) / \(\bar{\mathbb{L}}\).
- From direct memories : long press on KEY 1 or KEY 2 in idle mode.

#### Answer and end a call

- **(** / °**}**.

IMPORTANT NOTE: You can simply place the handset back on its base station or charger pod to end the call.

## Use handsfree (only for E190 Voice)

- To activate / desactivate handsfree : 1 1

# Adjust the earpiece volume

During a call, press ♠ or ▼ to select from VOLUME 1 to VOLUME 5.

# Mute / unmute microphone

- MUTE to turn on / off the microphone.

- Press located at the back of the base station. All the registered handsets start to ring.
- Once retrieved, press any key on the handset or the again to end the paging.

# Call waiting

If you have subscribed to Call Waiting service, the earpiece will emit a beep tone to inform you that there is a second incoming call. The number or name of the second caller will also be displayed on your phone if you have subscribed to Caller Line Identification service (CLI). Please contact your network provider for more information on this service.

#### Phonebook settings: 50 entries

# Store a contact in the phonebook

- MENU/ A or ▼ to select PHONEBOOK / DK / DK to enter NEW ENTRY / enter the name of contact / DK / enter the number of contact /DK / confirmation beep ( ⇒ to delete characters).

# Access phonebook

- ♥ or MENU to select PHONEBOOK /□K / A or ▼ to select LIST
- Note: Instead of pressing  $oldsymbol{\Delta}$  or  $oldsymbol{
  abla}$  to browse the phonebook entries, you can press the numeric key corresponding to the first letter of the entry you wish to locate.

#### Modify a phonebook entry

- MENU/ ♠ or ▼ to select PHONEBOOK / □K/♠ or ▼ to select EDIT ENTRY / □K / ♠ or ▼ to select an entry to edit / □K / current name is displayed / edit the name / OK/ edit the number /OK/ confirmation

# Delete a phonebook entry

- MENU/  $\triangle$  or  $\nabla$  to select **PHONEROOK** /  $\square$ **K** /  $\triangle$  or  $\nabla$  to select DELETE / OK/ ♠ or ▼ to select entry to delete / OK / OK/ confirmation beep.

# Delete all entries from the phonebook list

- MENU/  $\Delta$  or  $\nabla$  to select PHONEBOOK /  $\Box$ K /  $\Delta$  or  $\nabla$  to select **DELETE ALL** /OK/OK/ confirmation beep.

# Add / edit direct access memory

- MENU/ A or ▼ to select PHONEBOOK / NK/ A or ▼ to select DIRECT MEM. / □K / A or ▼ to select KEY 1 or KEY 2 / □K / stored name displayed, or NO NUMBER displayed if it is empty / MENU to

enter direct memory menu / ♠ or ▼ to select EDIT NUMBER / □K/ currently stored name displayed (or ENTER NAME if there is no number stored) / edit or enter the name / DK/ confirmation beep.

#### Delete direct access memory

- MENU/ A or ▼ to select PHONEBOOK / □K / A or ▼ to select DIRECT MEM. /OK / A or ▼ to select KEY 1 or KEY 2 / OK / stored name displayed (or NO NUMBER if it is empty) / MENU to enter direct memory menu / ♠ or ▼ to select DELETE / □K / □K / confirmation

#### Using the redial list

The redial list stores the last 5 numbers dialed

#### Access redial list

- REDIAL / ♠ or ▼ to browse the redial list / □K to view details.

## Save a redial number into the phonebook

- REDIAL / ♠ or ▼ to select an entry / MENU to display SAVE NUMBER / OK to display ENTER NAME / enter the name of contact (maximum 12 characters) / DK / return the display to redial list.
- Using the call log: stored up to 10 external calls

#### Access call log

- 🔓 / 🛦 or 🔻 / 🗆 K .

# Save call list entry into the phonebook

. A or ▼ to select an entry /MENU/ A or ▼ to select SAVE NUMBER / OK to select and enter the name of contact (maximum 12 characters) / DK.

#### Delete a Call Log entry

A or ▼/MENU/A or ▼ to select DELETE / OK / OK /

#### Delete all entries in the Call Log

A or ▼ to select DELETE ALL / OK / OK / confirmation

#### Answering machine setting

#### Answering machine operation by handset

You can use the answer machine menu on the handset to access and change the settings for all the answering machine functions.

#### Turn the answering machine on or off

MENU/A or ▼ to select ANSW MACHINE /DK /A or ▼ to select ANSW. ON / OFF / DK / A or ▼ to select ON or OFF / DK / confirmation beep.

Note: If the answering machine is turned off and the master PIN is still set at its default 0000, the answering machine will not answer to any incoming ringing, but if the master PIN has been changed, it will answer after 10 rings to allow remote access.

#### The outgoing message

The model is supplied with two predefined outgoing messages (OGM) used for the different answer modes.

#### There are 2 answer modes available: Answer Only and Answer & Record.

By default, the answer mode is ANSW.&RECORD, which allows a caller to leave a message on the answering machine. This can be changed to ANSWER ONLY mode, which does not allow callers to leave any messages on the answering machine

#### Set the answer mode

MENU/A or ▼ to select ANSW MACHINE / □K/A or ▼ to select ANSWER MODE /OK / A or ▼ to select ANSWER ONLY or ANSW &RECORD / TIK

# Record a personalised outgoing message

- MENU/ A or ▼ to select ANSW MACHINE / □K / A or ▼ to select RECORD OGM / □K / △ or ▼ to select ANSWER ONLY or ANSW.&RECORD / □K / A or ▼ to select RECORD OGM / □K to start recording / OK to end recording.

Note: The maximum length of an outgoing message is 3 minutes. To hear your outgoing message, select PLAY after selection of ANSWER ONLY or ANSWER&RECORD

#### To delete a personalised outgoing message and return to the predefined one, select **DELETE** after selection of **ANSWER ONLY** or ANSWER&RECORD.

# Playback and delete messages

The last recorded message is played first via the loudspeaker on model. Old messages cannot be played again until after all new messages have been played.

# Playback recorded messages

- MENU/ A or ▼ to select ANSW MACHINE / DK / DK to start playback. Note: During message playback you can press MENU key, then Navigation to select options to REPEAT the current message, skip forward to the NEXT message, skip back to the PREVIOUS message or DELETE the current message.

# Delete all recorded messages

- MENU/ ♠ or ▼ to select ANSW MACHINE / □K/ ♠ or ▼ to select DELETE ALL / OK.

# Set ring delay

MENU/ ♠ or ▼ to select ANSW MACHINE / □K / ♠ or ▼ to select SETTINGS / □K / □K to enter RING DELAY / A or ▼ to select 2 - 7 RINGS or ECONOMY / DK / confirmation beep.

Notes: If you select Economy mode, the answering machine will answer calls and start playing the greeting message after 5 rings if you have no new messages, or after 3 rings if there is at least one new message recorded.

#### To activate / deactivate remote control access

MENU/ A or  $\nabla$  to select ANSW MACHINE /  $\Pi$ K / A or  $\nabla$  to select SETTINGS / □K / A or ▼ to select REMOTE ACC / □K / A or ▼ to select ACTIVATE or DEACTIVATE / DK / confirmation been Notes: If the answering machine is turned off, you must change your master PIN from its default 0000, before you can use the remote access feature.

#### To check messages remotely

Dial your home phone number / while the answering machine playing greeting message /# ato dial and enter remote access code (master PIN code) / confirmation beep / message start playing Note: The answer machine will drop the line immediately if there is no detection of the master PIN entry within 8 seconds from pressing# a

#### The remote feature lets you perform the following functions:

То	Press this button
Review message	1
Play back messages	2
Stop message playback	8
Erase message	6 (during message playback)

Turn off answerer machine Note: If the answering machine is off, and the master PIN has been changed from its default 0000, it will answer the call after 10 rings. Dial the master PIN code within 8 seconds and you will hear a beep

to confirm you have entered the remote access mode, as above

# Set the OGM voice language (optional)

- MENU/ A or ▼ to select ANSW MACHINE / OK / A or ▼ to select SETTINGS / □K / A or ▼ to select LANGUAGE / □K / ▲ or ▼ to select your preferred language / □K / confirmation beep.

#### Call screening

Skip message

Turn on answerer machine

Call screening allows you to hear the caller while he is leaving a message

#### You can then decide if you want to talk to the caller directly. Using the intercom

- Intercom another handset
- If only 2 registered handsets: INT - If more than 2 registered handsets: the available handset number and \* displayed / enter the handset number
- To ring all handsets to intercom: ★ ⊷

#### Transfer an external call to another handset During the call:

- If only 2 registered handsets: INT - If more than 2 registered handsets: the available handset number
- and \* displayed / enter the handset number To ring all handsets to intercom: \* ... on the called handset to answer the internal call / of on the
- first handset transfer the external call to the called handset / external call tansferred. Note: If there is no answer from the called handset, press INT key

#### to resume the external call. Answer an external call during intercom

/ answer the external call and end the intercom. Note: To put the internal call on hold and answer the incoming external call, press INT kev.

# Switch between an internal and external call

to answer / long press DK on the first handset

- During the call, press and hold INT Establish a three-party conference call - During call, INT / enter handset number / \ on the called handset

CONFERENCE will be displayed on the screen once the

# conference call is established.

# Handset Tone

Set the ring volume There are 5 ringer volume options (OFF, LEVEL 1, LEVEL 2.

LEVEL 3, LEVEL 4 and LEVEL 5). The default level is LEVEL 3. - MENU/ A or ▼ to select PERSONAL SET / □K / A or ▼ to select HANDSET TONE / □K to select RING VOLUME / □K / A or  $\nabla$  to the desired volume level / DK / confirmation been.

#### Set the ring melody: 10 ring melodies

to select ON or OFF / DK/ confirmation beep

Activate / deactivate key tone

- MENU/ A or ▼ to select PERSONAL SET / DK / A or ▼ to select HANDSET TONE / □K / A or ▼ to select RING TONES / □K / **△** or **▼** to the desired melody / **□K** / confirmation beep.

- MENU/ ♠ or ▼ to select PERSONAL SET / DK / ♠ or ▼ to select

HANDSET TONE / OK / ♠ or ▼ to select KEY BEEP / OK / ♠ or ▼

#### Activate / deactivate auto hang-up

-MENU/ ♠ or ▼ to select PERSONAL SET / □K/♠ or ▼ to select AUTO HANG-UP / □K / △ or ▼ to select ON or OFF / □K / confiramtion beep.

#### Set date / time format

#### Set time format

- MENU / A or ▼ to select CLOCK&ALARM / DK / A or ▼ to select SET FORMAT / OK / OK to enter TIME FORMAT / current setting displayed / A or ▼ to select 12 HOURS or 24 HOURS / DK / confirmation been.

#### Set date format

- MENU/ ♠ or ▼ to select CLOCK&ALARM / □K/ ♠ or ▼ to select SET FORMAT / □K / ♠ or ▼ to select DATE FORMAT / □K / current setting display / ♠ or ▼ to select DD/MM or MM/DD / □K/ confirmation been

#### Set alarm

- MENU/ A or ▼ to select CLOCK&ALARM / DK / A or ▼ to select ALARM /DK / A or ▼ to select OFF. ON ONCE or ON DAILY /DK.

- if select ON ONCE or ON DAILY enter time (HH-MM) for alarm / ♠ or ▼ to select AM or PM if in 12 HOURS format / □K / confirmation beep.

#### Set alarm tone - MENU/ A or ▼ to select CLOCK&ALARM / DK / A or ▼ to select

Change Master PIN

ALARM TONE / □K / ♠ or ▼ to select MELODY 1, MELODY 2 or MELODY 3 / DK / confirmation been Advanced use of your telephone

The Master PIN is used for registration / unregistration of handsets. The default Master PIN number is 0000. Note: If you forget your PIN code, you can reset it to its default 0000 using a handset Reset

MENU/  $\triangle$  or  $\nabla$  to select **ADVANCED SET** /  $\square$ K/ $\triangle$  or  $\nabla$  to select

CHANGE PIN / OK / enter current master pin when prompted / OK /

# enter new PIN / DK / confirmation been

Register your handset IMPORTANT: Handset registration is only necessary when you buy extra handsets or if a handset has become faulty. Up to 4 handsets can be registered to one base station

The Master PIN is required before you can register or unregister handsets By default, the Master PIN is 0000

- On the base station, press and hold the key for 5 seconds - On the handset press MENU/ A or ▼ to select ADVANCE SET / □K / A or ▼ to select REGISTRATION / □K / enter Master PIN when prompted / DK / WAITING displayed / confirmation beep.

- MENU/ A or ▼ to select ADVANCE SET / □K / A or ▼ to select

#### UNREGISTER / OK / enter Master PIN when prompted / OK / A or ▼ to select the handset number to unregister / □K /

Unregister your handset

LONG / NK / confirmation been.

Change recall time - MENU/ A or ▼ to select ADVANCE SET / NK / A or ▼ to select RECALL TIME / □K / ♠ or ▼ to select SHORT, MEDIUM or

# Change the dial mode (dual mode dialing version only)

You should normally leave the dialling mode at its default setting of TONE (also called MF or DTMF). However, you can change to PULSE if necessary. Note: If PULSE dialling is set, you can press ★ ... to switch to TONE

dialling for the rest of that call. - MENU / ⚠ or ▼ to select ADVANCED SET / □K / ⚠ or ▼ to select DIAL MODE / □K / ▲ or ▼ to select TONE or PULSE / □K /

#### - MENU / ⚠ or ▼ to select ADVANCE SET / □K / ⚠ or ▼ to select RESET / OK / OK / confirmation been

Reset unit

Troubleshooting If you have difficulty with your phone, please try the suggestions

As a general rule, if a problem occurs, remove the batteries from all the handsets in your installation for about 1 minute. then disconnect and reconnect the power supply to the base and reinstall the handset batteries

Always check first

You have followed all the steps listed in the user
manual to install and set up your telephone

that:	All connectors are firmly inserted in their sockets.  Alians power to the base unit is switched on at the socket.  The handset's batteries are correctly and securely installed and are not run down.
Everyday use "I cannot make or answer calls"	If the handset's display is blank, it may have been switched off. Press and hold the HANG-UP/EXIT key to switch it back on. Check that the base unit's mains power adapter is plugged in and power is switched on. The base unit needs mains power for normal operation of the phone - not just for charging the batteries. Make sure you are using the telephone line cable supplied with your telephone. Other telephone line cables might not work. Move the handset closer to the base unit. Check the battery level symbol on the display. If it is low, replace the handset on the base unit or charger pod to recharge the batteries. Switch off power at the mains socket, wait for a short time and then switch back on. This may solve the problem.

#### 'I cannot make a If the handset display shows KEYS LOCKED, press and hold the \* button to unlock it before you make Only one handset (or the base unit) can be connected to the outside line at a time. If another handset is already using the line, you need to wait until it has finished its call. When I press on ake sure the batteries are fitted in your handset. the kevs, nothing If the Battery Level symbol on the display shows happens" low' put your handset back on the cradle to charge "When I key in a Try a different position for the base unit number, it appear here higher if possible, or further from other on the display, but electrical equipment. Try moving the handset closer to the base unit. The phone does Check that the base unit's mains power adapter is not rina" plugged in and power is switched or Check that ring volume is not on OFF. 'I hear 'beeps' from You may be going out of range of the base unit. Move closer or your call may be cut off. Check the Battery Level symbol on the display. my handset while If it's low, recharge the batteries, When I try to make If you're using a multi-handset system, check a call, I hear busy "The volume in the Make sure you're holding the earpiece correctly earpiece is low ver your ear Adjust the volume using the UP/DOWN key. when I'm on a call Before you first use the handset, you should have left it on the base unit or charger pod for 15 hours Batteries 'The handset's battery cells are to charge the batteries fully. You may need to eplace the batteries. Check the connection een the base unit and the mains power socke You need to replace the batteries. "I try to recharge the Dispose of used batteries safely – never burn them. get a warning that they are low" or put them where they could get punctured. Do not use non - rechargeable batteries in your handset they may explode, causing damage. Disconnect all other instruments connected to the ame line and try to make a call Disconnect the base unit from the telephone line and plug a different phone into the master If the fault persists telephone socket. Try making a call. If this works, the line is OK. If the call does not work, and you are using a twoway socket adapter, remove it and plug a telephon directly into the socket. If the call now works, the adapter may be faulty. If you cannot make a call, the fault may be on the

The store where you bought your telephone can also provide you with information and after - sales support.

This telephone is not designed for Emergency calls when the main nower fails Do not use your telephone to notify a gas leak or other potential

Do not open your device or its power supply to avoid risk of electrical shock. Do not attempt to open the batteries, as they contain hazardous chemical substances. Your telephone must be located in a dry place away from hot humide and direct sunlight condition. To avoid radio signal

interference, place the phone at least 1 meter away from other

# electrical appliances or other phones.

explosion hazard!

**ENVIRONMENT** This symbol means that your inoperative electronic appliance must be collected separately and not mixed with the household waste.

www.alcatel-home.com ATLINKS, 22 quai Gallieni 92150 Suresnes - France

Help us protect the environment in which we live!

© ATLINKS 2014 - Reproduction prohibited. The manufacturer reserves the right to modify the specifications of

with new regulations. ALCATEL and ATLINKS are registered trademarks. The Alcatel logo and Alcatel name are trademarks of Alcatel-Lucent and used under license by ATLINKS.

its products in order to make technical improvements or comply


E130 Voice / E130 Voice Duo / Trio E190 Voice / E190 Voice Duo / Trio A/W No.: 10001071 Rev.1 (LA-EN) Made in China

#### Lea estas indicaciones antes de usar su teléfono Conexión del teléfono

- Conecte los enchufes en las tomas correspondientes en la estación base. Conecte el cable de la línea telefónica en la toma telefónica e inserte el adaptador de alimentación a una
- Coloque las baterías en el auricular.

Antes de empezar a usar el teléfono, asegúrese de que las baterías havan sido cargadas totalmente durante 15 horas.

▲ Use siempre el adaptador de alimentación y las baterías que se adjuntan en la caja.




#### Teclas de funcionamiento del teléfono

- 1 Tecla OK
- 2 Tocla Atrás
- Tecla de Navegación
- Tecla Hablar/Altavoz (Sólo para E190 Vocie)
- Tecla Colgar / Salir
- 6 Tecla FLASH Accede a los servicios del operador\*
- 7 Tecla de Menú
- Tecla de Rellamada
- 9 Tecla de Asterisco Para bloquear / desbloquear el teclado. - Para cambiar entre llamadas internas y externas cuando ambas están configuradas
- 10 Tecla Almohadilla
- 11 Tecla de Silenciar(Mute
- 12 Tecla de Transferencia de Llamadas / Intercomunicador

# Estación hase

**=** 



Botón localizador del teléfono Púlselo y manténgalo pulsado para iniciar el nrocedimiento de registro

# ¿ Qué aparece en pantalla?

- Muestra íconos. Aparece en modo menú para confirmar su
- Indica que están disponibles más opciones. Use las teclas ARRIBA / ABAJO para zarse hacia arriba / hacia abajo

# ¿Qué significan los íconos?

Indica que la batería está totalmente cargada.

Indica que la batería está totalmente descargada Indica que está conectado o en espera de una llamada

El ícono parpadea al recibir una llamada entrante

o Indica que ha recibido un nuevo mensaje de correo de voz.\*

Indica que tiene nuevas llamadas perdidas o que se está

revisando el registro de llamadas.\* Aparece cuando se accede a la agenda.

Aparece cuando se activa el manos libres (sólo Sigma 260 Voice).

Aparece cuando se desconecta el volumen del sonido. Indica que el teléfono está registrado y dentro de la

cobertura de la estación base.

El ícono parpadea cuando el teléfono está fuera de cobertura o está buscando una base.

OK Aparece en modo menú para confirmar su selección.

Indica que están disponibles más opciones.

▲▼ Use las teclas ARRIBA / ABAJO para desplazarse hacia arriba / hacia abaio.

Aparece cuando está en modo menú.
Pulse la tecla ATRÁS para volver al nivel de menú anterior. \* Suieto a suscripción y disponibilidad de servicio del operador de

# Las operaciones del teléfono

# Conexión / desconexión

- Pulse y mantenga pulsada la tecla \*

Notas: Cuando el teléfono está DESCONECTADO no se puede utilizar para hacer llamadas incluyendo llamadas de emergencia. Éste no sonará durante una llamada entrante.

Para responder a una llamada tendrá que volver a conectarlo. El teléfono puede tardar cierto tiempo en restablecer un enlace de radio con la unidad base.

#### Para bloquear / desbloquear el teclado

- Pulse v mantenga pulsada la tecla \* ....

Nota: Todavía se pueden responder a las llamadas entrantes aunque el teclado esté bloqueado.

#### Cambiar el idioma de pantalla

- MENU/ ♠ ó ▼ para seleccionar AJUSTES PERS / □K / ♠ ó ▼ para seleccionar IDIOMA / □K / ♠ ó ▼ para seleccionar el idioma que desee / DK / se reproduce un pitido de confirmación Nota: Una vez que se configura el idioma, los menús de opciones del teléfono cambiarán en la pantalla en el idioma seleccionado de forma inmediata.

# Configurar fecha y hora

Nota: Si está suscrito al servicio de identificación de llamadas, la hora y la fecha se fijarán de forma automática cuando reciba una llamada: aunque todavía puede requerir fijar el año correcto.

- MENU/ A ó ▼ para seleccionar RELOJ&ALARMA / □K/ □K para seleccionar DIA / HORA / aparece la última fecha guardada / introduzca la fecha actual (YY - MM - DD) / DK / posteriormente introduzca la hora (HH-MM) / DK.

#### Cambiar el nombre del teléfono

- MENU/ A ó ♥ para seleccionar AJUSTES PERS / OK / A ó ♥ para seleccionar NOMBRE TELF / DK / aparece el nombre actual del teléfono / para borrar los caracteres uno a uno / introduzca el Nuevo nombre (máximo 10 caracteres) / DK / se reproduce un pitido de confirmación.

#### Realizar y recibir llamadas

Realizar una llamada

antes o después de marcar el número de teléfono:

Desde la lista de rellamadas: REDIAL / ▲ Ó ▼ / 🕻

- Desde el registro de llamada\*: 🛕 / 🛕 ó 🔻 / 🕻 . Nota: Es necesario estar suscrito al servicio de identificación de llamadas para poder ver el número de la persona que llama o el nombre en el registro de llamada:

- Desde la agenda: ♥ / ♠ ó ♥ / •

- Desde las teclas de memorias directas: en modo inactivo, pulse y mantenga pulsado TECLA 1 ó TECLA 2.

#### Responder v finalizar una llamada

- t / o.t.

NOTA IMPORTANTE: Simplemente puede volver a colocar el teléfono en la estación base o cargador para finalizar una llamada.

Uso del manos libres (sólo para E190 Voice)

#### Aiustar el volumen del micrófono

Durante una llamada pulse ▲ ó ▼ para seleccionar VOLUMEN 1 a VOLUMEN 5

# Silenciar (Mute) / dar volumen al micrófono

- MUTE para conectar / desconectar el micrófono.

# Buscar un teléfono (función paging)

- Pulse la tecla 🐧 situada en la parte posterior de la estación base. Todos los teléfonos registrados empiezan a sonar.

- Una vez recuperado, pulse cualquier tecla del teléfono para detener el timbre o pulse nuevamente la tecla

# Configuración del contestador

Manejo del contestador mediante el teléfono

#### Activar o desactivar el contestador

- MENU / ♠o ♥ para seleccionar ANSW MACHINE / □K / ♠o ♥ para seleccionar ANSW. ON/OFF/□K / ♠o ▼ para seleccionar ON o OFF/□K/pitido de confirmación.

#### El mensaie de salida Configure el modo de respuesta

- MENU/Ao ♥ para seleccionar ANSW MACHINE/□K/Ao ♥ para seleccionar ANSWER MODE/ □K / ♠ o♥ para seleccionar ANSWER ONLY & ANSW & RECORD/ OK

# Grabe un mensaje de salida personalizado

- MENU / A o ▼ para seleccionar ANSW MACHINE/ □K / A o ▼ para ONLY o ANSW.&RECORD/ **□K** / **△**o **▼** para seleccionar RECORD OGM/DK para comenzar a grabar/(DK) para finalizar la grabación.

#### Reproducir y borrar mensajes

# Reproducir mensajes grabados

MENU/Ao ♥ para seleccionar ANSW MACHINE/□K/□K para iniciar la reproducción.

Durante la reproducción de un mensaje (MENU), vaya a Navegación para seleccionar las opciones para BORRAR el mensaje actual.

# Establezca el retardo del timbre - MENU / Ao ♥ para seleccionar ANSW MACHINE / OK / A o ♥ para

seleccionar SETTINGS/ OK / OK para introducir RING DELAY/ Ao ▼para seleccionar 2 - 7 RINGS o ECONOMY/ OK /pitido de

## Para verificar los mensaies de forma remota

 Marque su número de teléfono /mientras el contestador reproduce el mensaje de respuesta / # g para marcar e introducir el código de acceso remoto (código PIN maestro)/ pitido de confirmación/ el mensaje comienza a reproducirse

# La función remota le permite realizar las siguientes funciones:

Para	Presionar este boton
Volver a ver el mensaje	1
Reproducir mensajes	2
Detener la reproducción del mensaje	8
Borrar mensaje	6 (durante la reproducción
	del mensaje)
Saltar mensaje	3
Activar el contestador	7
Desactivar el contestador	9

#### Establecer el idioma de voz OMG (opcional)

MENU/ △ o ▼ para seleccionar ANSW MACHINE/ OK / △ o ▼ para seleccionar SETTINGS/ OK / △ o ▼ para seleccionar LANGUAGE/ OK / A o ▼ para seleccionar su idioma preferido/ OK /pitido de

#### Llamada en espera

Si está suscrito al servicio de llamada en espera, el micrófono emitirá un pitido para informarle que hay una segunda llamada

El número o nombre de la segunda persona que llama se muestra en el teléfono si está suscrito al servicio de identificación de llamadas. Por favor, póngase en contacto con su proveedor de red para obtener más información sobre este servicio.

#### Uso de la agenda: 50 entradas

#### Guardar un contacto en la agenda

- MENU/ A ó ▼ para seleccionar AGENDA / OK / OK para introducir una NUEVA ENTR. / introduzca el nombre / DK / introduzca el número / DK / se reproduce un pitido de confirmación ( 🗢 para borrar caracteres).

#### Acceder a la agenda

 $\stackrel{\mathfrak{O}}{=}$  ó MENU para seleccionar **AGENDA** /  $\mathbb{O}K$  / las entradas de la agenda se enumeran en orden alfabético y se puede pulsar la tecla de Navegación para desplazarse a través de las entradas quardadas / NK

Nota: En vez de pulsar la tecla de Navegación, para buscar las entradas de la agenda, puede pulsar la tecla numérica que corresponde a la primera letra de la entrada que desee localizar.

#### Modificar una entrada de la agenda

-MENU/ ♠ ó ♥ para seleccionar AGENDA / ŪK / ♠ ó ♥ para seleccionar EDIT. ENTR / □K / ♠ ó ▼ para seleccionar una entrada / NK / se muestra el nombre actual / edite el nombre / NK / edite el número / DK / se reproduce un pitido de confirmación.

# Borrar una entrada de la agenda

- MENU/ A ó ▼ para seleccionar AGENDA / □K/A ó ▼ para seleccionar BORRAR /OK/ ♠ ó ▼ para seleccionar una entrada a borrar / OK / OK / se reproduce un pitido de confirmación.

#### Borrar todas las entradas de la lista de la agenda

- MENU/ A ó ♥ para seleccionar AGENDA / OK/ A ó ♥ para seleccionar BORRAR TODO / DK / DK / se reproduce un pitido de confirmación

# Añadir / editar el acceso a la memoria

- MENU/A ó ▼ para seleccionar AGENDA / □K/A ó ▼ para seleccionar MEM. DIRECTA / OK / ♠ ó ♥ para seleccionar TECLA 1 ó TECLA 2 / DK / aparece el nombre guardado y SIN NÚMERO si está vacía / si no hay un número guardado en la tecla seleccionada o si desea cambiar el nombre o el número que está guardado, pulse MENU para entrar en el menú de la memoria directa para añadir / editar el nombre o el número / ♠ ó ▼ para seleccionar FDITAR NUM / ΠΚ / la nantalla muestra el nombre guardado actual o INTRO NOMB si no hay un nombre guardado, edite o introduzca el nombre que desee / DK / se reproduce un pitido de confirmación

#### Borrar el acceso directo a la memoria

- MENU/A ó ♥ para seleccionar AGENDA / □K / A ó ♥ para seleccionar MEM, DIRECTA / DK / A ó ▼ para seleccionar TECLA 1 ó TECLA 2 / DK / aparece el nombre guardado (o SIN NÚMERO si va está vacía) / MENU para entrar en el menú dememoria directa / ⚠ ó ▼ para seleccionar SUPRIMIR / OK / OK / se reproduce un pitido de confirmación.

# Usar la lista de rellamada

La lista de rellamada guarda los últimos 5 números marcados. - REDIAL / ♠ ó ▼ para buscar en la lista de rellamada / OK para ver los detalles de la entrada seleccionada.

# Guardar un número marcado en la agenda

- REDIAL/♠ ó ♥ para seleccionar una entrada / MENU para mostrar GUARDAR NUM. / DK para mostrar INTRO. NOMB. / introduzca el nombre del contacto (máximo 12 caracteres) / DK / volver a la pantalla de la lista de rellamada.

#### Usar el registro de llamadas: almacena hasta 10 llamadas externas

# Borrar una entrada del registro de llamadas

A ó ▼ /MENU / A ó ▼ para seleccionar BORRAR / □K/□K/ se reproduce un pitido de confirmación.

Borrar todas las entradas del registro de llamadas

#### - ♣ /MENU/ ♠ ó ♥ para seleccionar BORRAR TODO / □K/ □K / se oduce un pitido de confirmación. Usar el intercomunicador

Intercomunicar con otro teléfono

- Si sólo 2 teléfonos están registrados: INT

- Si más de 2 teléfonos están registrados: aparecerán los números de los teléfonos que están disponibles para la intercomunicación y un \* / introduzca el número del auricular

#### - Para usar el modo intercomunicador: ★ ⊷. Transferir una llamada externa a otro teléfono

Durante la llamada

Si sólo 2 teléfonos están registrados: INT.

- Si más de 2 teléfonos están registrados: aparecerán los números de los teléfonos que están disponibles para la intercomunicación v un \* / introduzca el número del auricular.
- Para usar el modo intercomunicador: ★ →

- t en el teléfono al que se llama para responder a la llamada interna con el fin de que puedan hablar de forma interna las dos personas que llaman / \* en el primer teléfono para transferir la llamada externa al teléfono al que se llama / se transfiere la

llamada externa. Nota: En caso de que no hava respuesta del teléfono al que se llama, pulse la tecla INT para volver a la llamada externa.

# Responder a una llamada externa durante una llamada

- 🕻 / para responder a la llamada externa y acabar con la intercomunicación.

Nota: Para poner en espera y responder a la llamada entrante externa pulse la tecla INT

#### Cambiar entre una llamada interna y una externa

- Durante la llamada, pulse INT

#### Establecer una llamada de conferencia a tres - Durante una llamada, INT / introduzca el número del auricular al que desea llamar / 🐧 en el auricular al que se llama para responder / y mantenga pulsada DK en el primer teléfono para iniciar la conferencia a tres bandas.

Aparecerá en pantalla CONFERENCIA una vez que se establezca la llamada de conferencia.

# Tono del teléfono

# Fiiar el volumen del timbre

Existen 5 opciones de volumen de timbre (DESACTIVADO, NIVEL 1, NIVEL 2, NIVEL 3, NIVEL 4 y NIVEL 5).

El nivel configurado de fabricación es el NIVEL 3.

- MENU/ A ó ♥ para seleccionar AJUSTES PERS / □K/A ó ♥ para seleccionar TONOS TELF / DK para seleccionar y mostrar VOL. TIMBRE /□K/ A ó ▼ para alcanzar el nivel de volumen que desee / DK / se reproduce un pitido de confirmación.

# Fijar la melodía de llamada: 10 melodias

- MENU/ A ó ♥ para seleccionar AJUSTES PERS / OK / A ó ♥ para seleccionar TONOS TELF / □K / ♠ ó ▼ para seleccionar TONOS TELF /□K / ♠ ó ▼ para fijar la melodía que desee / □K / se reproduce un pitido de confirmación

#### Activar / desactivar el tono de tecla - MENU/ A ó ♥ para seleccionar AJUSTES PERS / □ K / A ó ♥ para

seleccionar TONOS TELF / □K / ♠ ó ▼ para seleccionar TONO TECLA / OK / ▲ ó ▼ para seleccionar ACTIV. ó DESACTIVADO /DK/ se reproduce un pitido de confirmación

# Activar / desactivar colgar automáticamente

- MENU/ A ó ▼ para seleccionar AJUSTES PERS / □K / A ó ▼ para seleccionar COLGAR AUTO / □K / ♠ ó ▼ para seleccionar ACTIV. ó DESACTIVADO / DK / se reproduce un nitido de confirmación

- MENU/ A ó ▼ nara seleccionar RELO.I&ALARMA / NK / A ó ▼ nara seleccionar AJUST FORM /OK /OK para entrar en FORMATO HORA / se muestra la configuración actual /♠ ó ♥ para seleccionar 12 HORAS ó 24 HORAS / DK / se reproduce un pitido

# Fijar el formato de fecha

de confirmación

Fijar el formato de hora

Fijar el formato de fecha y hora

MENU/A ó ▼ para seleccionar RELOJ&ALARMA /□K/A ó ▼ para seleccionar AJUST FORM / DK / A ó ▼ para seleccionar FORMAT FECHA /□K / se reproduce un pitido de confirmación / A ó ▼ para seleccionar DD/MM ó MM/DD / UK/ se reproduce un pitido de

# Configurar la alarma

- MENU/ A ó ▼ nara seleccionar RELO.I&ALARMA / NK / A ó ▼ nara seleccionar ALARMA /□K/A ó ▼ para seleccion DESACTIVADO / UNA SOLA VEZ / A DIARIO / DK
- · Si ha seleccionado UNA SOLA VEZ ó A DIARIO, introduzca la hora (HH-MM) de la alarma / ♠ ó ♥ para seleccionar AM ó PM si la hora está en formato de 12 horas /DK/ se reproduce un pitido de confirmación.

- MENU/ ♠ ó ♥ para seleccionar RELOJ&ALARMA / ŪK / ♠ ó ♥ para seleccionar TONO ALARMA /□K / 🛦 ó 🔻 para seleccionar MELODÍA 1. MELODÍA 2 ó MELODÍA 3 /ÚK/ se reproduce un pitido de confirmación

# Uso avanzado de su teléfono

Configurar el tono de la alarma

# Cambio del PIN máster

El PIN máster se usa para el registro y anulación de registro de los teléfonos.

El número PIN máster por defecto es 0000. Nota: En caso de que olvide su código PIN, puede reiniciarlo al

0000 (por fabricación) usando un reinicio de teléfono. MENU/ ⚠ ó ▼ para seleccionar AJUSTE AVANZ / OK/ ⚠ ó ▼ para seleccionar CAMBIAR PIN / DK/ introduzca el PIN máster actual cuando se le pida / DK/ introduzca el Nuevo PIN / DK/ se reproduce un pitido de confirmación.

# Registrar su teléfono

IMPORTANTE: El registro del teléfono sólo es necesario cuando adquiere teléfonos extras o si el teléfono está defectuoso. Se pueden registrar hasta 4 teléfonos a una estación base. Es necesario el PIN máster antes de que pueda registrar o anular el registro de teléfonos. Introduzca el PIN máster cuando se le pida v posteriormente pulse la tecla OK para confirmarlo. (El PIN máster por fabricación es 0000) Por fabricación, el PIN máster es 0000. - En la estación base, pulse y mantenga pulsada la tecla

LOCALIZADOR DE TELÉFONO durante aproximadamente 5 segundos / En el teléfono, pulse MENU/ ▲ ó ▼ para seleccionar AJUSTE AVANZ / □K / ♣ ó ▼ para seleccionar REGISTRO /NK/ aparece en pantalla ESPERANDO / se reproduce un pitido de confirmación.

#### Anular el registro de su teléfono

- MENU / A ó ♥ para seleccionar AJUSTE AVANZ / OK / A ó ♥ para seleccionar ANULAR REG / OK/ introduzca el PIN máster cuando se le pida / □K / ♠ ó ▼ para seleccionar el número del teléfono al que anular el registro / DK/ se reproduce un pitido de

# Ajustar el tiempo del corte calibrado (flashing)

MENU/ ♠ Ó ▼ para seleccionar AJUSTE AVANZ / □K/♠ Ó ▼ para seleccionar TIEMPO RELL. / □K / ♠ ó ▼ para seleccionar CORTO, MEDIO ó LARGO / □K/ se reproduce un pitido de confirmación / en la red de comunicación española. la duración

#### Cambio del modo de marcación

- MENU / A ó ▼ para seleccionar AJUSTE AVANZ / OK / A ó ▼ para seleccionar MODO MARCADO /□K / □K / ♠ ó ▼ para seleccionar TONO ó PULSO / DK / se reproduce un pitido de confirmación

#### Reiniciar la unidad

- MENU / ⚠ ó ▼ para seleccionar AJUSTE AVANZ / □K / 爲 ó ▼ para seleccionar RESTAURAR / DK / DK / se reproduce un pitido de confirmación

#### Problemas y soluciones

De manera general, en caso de problemas, retirar las baterías de todos los teléfonos de la instalación durante aproximadamente 1 minuto, luego desconectar y volver a conectar la alimentación eléctrica de la base e instalar nuevamente las baterías.

"No puedo realizar una llamada"	Si la pantalla del teléfono muestra TECLADO BLOQ, pulse y mantenga pulsado la tecla " para desbloquearlo y antes de que pueda realizar una llamada.
"Cuando pulso las teclas no pasa nada"	Asegúrese de que las baterías estén colocadas en el teléfono. Si el símbolo del nivel de batería en pantalla muestra "bajo", vuelva a colocar el teléfono en el cargador para cargarlo.
"Cuando pulso un número, aparece en pantalla pero no puedo hacer una llamada externa"	Pruebe colocando la unidad base en una posició diferente – en algún lugar más elevado si es posible o alejada de otros equipos eléctricos.
"El teléfono no funciona"	Compruebe que el adaptador de la unidad base está conectado y la corriente encendida. Compruebe que el volumen del pitido no está er la posición de DESACTIVADO.
"No puedo hacer o recibir llamadas"	Si la pantalla del teléfono está en blanco, puede que se haya desconectado. Pulse y mantenga pulsada la tecla COLGAR / SALIR para volverlo conectar.  Compruebe que el adaptador de alimentación d la unidad base esté conectado y la alimentación encendida.  La unidad base requiere alimentación para el normal funcionamiento del teléfono — no sólo pa cargar la batería  Asegúrese que usa el cable de línea telefónica que se suministra con el telefóno. Puede que no funcionen otros cables de línea telefónica.  Mueva el telefóno más cerca de la unidad base. Compruebe el símbolo del nivel de batería en la pantalla.  Si está baja, sustituya el teléfono en la unidad base o en el cargador para recargar la batería.  Apague la corriente del enchufe de alimentación espere un poco y posteriormente vuelva a encenderio.  Esto puede resolver el problema.
"Oigo "pitidos" procedentes del teléfono cuando estoy llamando"	Puede que esté fuera de cobertura de la unidad base. Acérquese o puede que se corte la llamada. Compruebe el símbolo de nivel de batería en la pantalla. Si está bajo, recargue la batería.
"El volumen del auricular es bajo cuando realizo una llamada"	Ajuste el volumen usando la tecla ARRIBA / ABAJ
Baterías "La batería del teléfono está baja en una hora o dos"	Antes de que use el teléfono debe haberlo cargando durante 15 horas para cargar completamente la batería. Puede que sea necesario sustituir la batería. Compruebe la conexión entre la unidad base y enchufe de alimentación.
"Intento recargar la batería pero recibo una advertencia de que está baja"	Es necesario que sustituya la batería.  Deshágase de la batería de forma segura – nunca la queme o la coloque en algún lugar donde pueda pincharse.  No use una batería no recargable en su teléfono puede explotar provocando daños.


#### SEGURIDAD

Usted no podrá llamar ni recibir llamadas de emergencia en caso de fallo del adaptador de alimentación de red

No use el teléfono para avisar de una fuga de gas si se encuentra en las cercanías de dicha fuga. No intente abrir el dispositivo o las fuentes de alimentación para evitar el riesgo de una descargar eléctrica. No intente abrir la batería va que

contiene sustancias químicas. El teléfono debe mantenerse alejado de toda fuente de excesivo calor (radiadores, luz solar, etc...) y protegido contra las vibraciones y el polvo. Para limitar los riesgos de interferencias, se recomienda instalar el teléfono por lo menos a 1 metro de otras fuentes de electricidad.

# MEDIO AMBIENTE



debe desechar de forma independiente y nunca junto a los

ww.alcatel-home.com

ATLINKS, 22 quai Gallieni 92150 Suresnes - Franica

© ATLINKS 2014 - Reproducción prohibida El fabricante se reserva el derecho de modificar sin previo aviso las características de sus productos para introducir mejoras técnicas o cumplir con nuevas regulaciones oficiales.

El logotipo y el nombre de ALCATEL son marcas registradas de ALCATEL-LUCENT utilizadas bajo licencia por ATLINKS.

> E130 Voice / E130 Voice Duo / Trio F190 Voice / F190 Voice Duo / Trio A/W No.: 10001071 Rev.1 (LA-SP)